It is a requirement that the webeyeFOG is subjected to the following checks at least once every 12 months and serviced in accordance with manufacturer's recommendations.

| Action: | | Completed: Y / N / NA | Comments: |
|--|-----------|--------------------------|-----------|
| Power down / deactivate webeyeFog from Alarm activation system. | | | |
| 2. Check WF for signs of damage, internal and external. | | | |
| Check fixings to ensure WF is securely and correctly fixed and has not been moved or re-orientated. | | | |
| Check adequate ventilation around WF as per manufacturers guidelines | | | |
| 5. Check WF cannister discharge port is free from obstruction and blockages, clear if necessary. | | | |
| 6. Check power cable is correctly fitted and not damaged. If battery powered, check voltage is within the manufacturer's parameters for correct operation. | | | |
| 7. Check LED indicators are working correctly in accordance with manufacturer guidelines. | | | |
| 8. Check alarm input connections on WF are correct and secure. | | | |
| 9. *Test mode - Check WF tamper switches operate correctly | | | |
| 10. *Test mode - Check siren activates | | | |
| 11. Ensure WF is correctly powered up / and reactivated to Alarm activation system. | | | |
| Certified checks carried out as above: | | | |
| Service Engineer Signature: | Custor | Customer Signature: | |
| Date: | re: Date: | | |

WEB: www.webeyecms.com